

Product Change Notification

H-811.S2/H-811.F2

Change Description

The connecting cables of the H-811.S2 and H-811.F2 hexapods now have a length of 0.5 m. Those are permanently installed on the hexapod. A drag chain compatible cable set (3 m), which consists of a data transmission cable, a power supply cable, and a connector holder, are included in the delivery.

Impact and Reasons

Cables have been harmonized with the H-811.I2 hexapod, that already features those types of cables. In the event of drag chain applications, this setup reduces stress on cables and the hexapod itself.

Recommended Action

The user should always use the supplied connector holder to affix the permanently installed cable to the surface.

Affected Products

Product number	Change	Effective date	Successor
H-811.S2		01.05.2019	
H-811.F2		01.05.2019	